
edge of ~1/2" glareshield flange behind panel
edge of EFIS cutout
edge of EFIS lip
nutplate
N
switch guards
security starter switch behind panel
ALT WARN
ALT
5.0
PRESS TO RESET
STARTER ENGAGED
ALT/BAT
up: + MAIN
ctr: BAT ON
EFIS PWR
up: + MAIN
ctr: B/U ON
FUEL PUMP
ON
LEFT MAG
ON
RIGHT MAG
ON
PUSH START
OFF
PRIMER
PULL ON
CABIN HEAT
PULL ON
piano hinge
30 deg. main panel
vertical 1.5" subpanel